

#### QUICK CARD

## Fiber Inspection with the OneAdvisor 800

This Quick Card outlines how to use the P5000i Fiber Inspection Microscope to inspect common single mode fiber end faces.



Figure 3: P5000i and OneAdvisor 800 P5000i Microscope

Magnification |

control

Retaining

nut

**Barrel** 

Assembly


Control



## QUICK CARD

### SET UP THE P5000i

- 1. Press the **Home** button to display the home screen and press **Tests** to display test selections.
- 2. Select **Fiber Inspection >** and tap the **Microscope** icon.
- 3. Tap the **Setup** soft key






Figure 4:Home Screen

Figure 5:Test Setup

4. Configure **Tip Setting** and **Profile** per the table below. If the Tip Selection is not shown on the OneAdvisor, connect the OneAdvisor to a PC with FiberChekPRO™ software using a USB to MicroUSB cable and move the appropriate tip setting onto the OneAdvisor. For more information, consult the FiberChekPRO user manual. To download FiberChekPRO to your PC, visit <a href="http://fcpro.updatemyunit.net/">http://fcpro.updatemyunit.net/</a>.

Connection Type		Tip	Profile Selection	Tip Selection
LC	Bulkhead	U	SM UPC (IEC-61300-3-35 Ed. 2.0)	Standard Tips (with BAP1)
	Patch Cord		SM UPC (IEC-61300-3-35 Ed. 2.0)	Standard Tips (with BAP1)
SC-UPC	Bulkhead		SM UPC (IEC-61300-3-35 Ed. 2.0)	Standard Tips (with BAP1)
	Patch Cord	ļ	SM UPC (IEC-61300-3-35 Ed. 2.0)	Standard Tips (with BAP1)
SC-APC	Bulkhead	-	SM APC (IEC-61300-3-35 Ed. 2.0)	Standard Tips (with BAP1)
	Patch Cord		SM APC (IEC-61300-3-35 Ed. 2.0)	Standard Tips (with BAP1)
Corning OptiTap	Bulkhead		SM APC (IEC-61300-3-35 Ed. 2.0)	FBPT-COD-L
	Patch Cord	<u> </u>	SM APC (IEC-61300-3-35 Ed. 2.0)	Standard Tips (with BAP1)
Corning OptiTip	Bulkhead		Ribbon, SM APC (IEC-61300-3-35 Ed. 2.0)	Ribbon Tips
	Patch Cord		Ribbon, SM APC (IEC-61300-3-35 Ed. 2.0)	Ribbon Tips





#### QUICK CARD


### INSPECT THE BULKHEAD


- 1. Set up the P5000i as described on page 2.
- 2. Press the **Back** soft key to return to the inspection screen.














- ▶ Press the **Test** button on the P5000i.
- ► Tap the **Test** soft key on the OneAdvisor.
- A green checkmark indicates a PASS result. A red X indicates a FAIL result.
- 7. Tap the **Live** soft key on the OneAdvisor to return to the Live fiber view.
- 8. If the test failed, clean the fiber end-face and re-run the inspection test. Repeat until it passes.



Figure 6: LC Bulkhead



Figure 7: SC APC Bulkhead



Figure 8: OptiTap Bulkhead



Figure 9: OptiTip Bulkhead




Figure 10: Live Inspection




Figure 11: Pass/Fail Analysis



#### QUICK CARD

### INSPECT THE PATCH CORD

- 1. Insert the Patch Cord into the Inspection tip:
  - For SC-APC Patch Cord inspection through an SC-SC Optical Coupler, insert the Patch Cord into the SC APC optical coupler. The Patch Cord, coupler, and tip are all keyed and the keys must be aligned.
  - For OptiTap and SC-APC Patch Cord Inspection without an Optical Coupler, insert the Patch Cord into the 2.5mm APC Patch Cord inspection tip. Rotate fiber and align the connector key to the notch on inspection tip for proper alignment.
  - > For **OptiTip Patch Cord** Inspection, slide the bulkhead adapter onto the main tip assembly. Rotate wheel to view and test each fiber.



Figure 13: SC APC Patch Cord




Figure 14: OptiTap Patch Cord







Figure 15: OptiTip Patch Cord



- 3. Press the **Back** soft key to return to the inspection screen.
- 4. Adjust the **Focus Control** wheel of the P5000i microscope to focus the optical fiber.
- 5. There are 2 ways to run the inspection test:
  - ▶ Press the **Test** button on the P5000i.
  - ► Tap the **Test** soft key on the OneAdvisor.
- A green checkmark indicates a PASS result.
  A red X indicates a FAIL result.
- 7. Tap the **Live** soft key on the OneAdvisor to return to the Live fiber view.
- 8. If the test failed, clean the fiber end-face and re-run the inspection test. Repeat until it passes.




Figure 15: Live Inspection




Figure 16: Pass/Fail Analysis



To reach the VIAVI office nearest you, visit viavisolutions.com/contact

<sup>© 2023</sup> VIAVI Solutions, Inc, Product specifications and descriptions in this document are subject to change without notice. Patented as described at viavisolutions.com/patents